AJOYO TECH RIDER

REQUIRED INSTRUMENTS

DRUMS

20 bass drum, 10 or 12 tom and 14 floor tom 14 snare drum, 3 cymbal stands, drum throne (pref round) Monitor on left side next to hi-hat stand

PIANO-KEYBOARDS

Acoustic grand piano (Yamaha or Steinway preferred) Nord Electro 5D 61 Keys Moog Little Phatty (2) X-style single-tier keyboard stands (2) DI boxes (Radial Pro-series preferred) (1) piano style sustain pedal (Yamaha FC4 preferred) (2) expression pedals (Yamaha FC7 preferred) (1) drum throne with round seat Keyboards stacked at 90 degrees to piano, to the right side. Two wedges required — one to the left of the piano and one to the right of the keyboards. Same monitor mix.

GUITAR

VOX AC 30 or Fender twin reverb Guitar stand Quad box

BASS

Aguilar or Ampeg amplifier Guitar stand

VOICE

Boom mic stand Two XLR cables (one line coming from board) Power access at feet (Using a TC Helicon VoiceLive Touch 2 Pedal)

7 STAGE MONITORS

INPUT LIST

- CHANNEL 1: lead vocals: 1 vocal mic + DI BSS audio AR133 for multi effect pedal
- CHANNEL 2: saxophones: 1mic type Sennheiser MD421-II
- CHANNEL 3: DI keyboard
- CHANNEL 4: Percussions
- CHANNEL 5: Percussions
- CHANNEL 6: Electric bass DI +miced bass amp
- CHANNEL 7: Drums overhead
- CHANNEL 8: Drums overhead
- CHANNEL 9: Bass drums type beta 98
- CHANNEL 10: Snare top type SM57
- CHANNEL 11: Snare bottom type SM57
- CHANNEL 12: Hi-hat
- CHANNEL 13: Guitar DI + miced amp
- CHANNEL 14: Vocal Mic: talk + background vox (sax)
- CHANNEL 15: Vocal mic background (guitar)
- CHANNEL 16: Vocal mic background (bass)

Please contact Yacine Boulares for any additional questions:

+16469184981 yacineboulares@gmail.com